

TRS Ruckus Stem

Installation Guide

This install will take ~20 minutes depending on how familiar you are with your bike and tools.

Warning: This stem requires the use of your OEM curved washer that comes with the original handlebars.

Before installation, double check to make sure you have all these components.

ITEM#	QTY	COMPONENT DESCRIPTION
1	1	TRS Stem body and Cap
2	1	M10x45mm long stainless bolt
3	1	M10 stainless locknut
4	4	M5 stainless cap bolts
5	1	Install manual

