



INSTRUCTIONS FOR NCY CDI ITEM NUMBER 0900-1076 UNLIMITED CDI

INSTRUCTIONS FOR NCY CDI ITEM NUMBER 0900-1076 UNLIMITED CDI
READ ALL INSTRUCTIONS FIRST BEFORE INSTALLING CDI.

- TAKE BATTERY BOX APART
- PLUG MODIFIED NCY HARNESS OUT OF BOX AND PLUG 5 WIRE PLUG IN TO CDI
- FIND BLACK W/ YELLOW TRACER WIRE AT ECU & CUT IT LEAVING ROOM TO ADD SUPPLIED CONNECTOR OR SOLDER.
- THE BLK/YELLOW TRACER WIRE YOU JUST CUT HANDING FROM THE ECU PLUG CONNECT SUPPLIED CONNECTOR/PLUG OR SOLDER YELLOW WIRE FROM NCY CDI HARNESS. (SEE PIC)
- AT THE OTHER END OF THE BLK/YELLOW TRACER WIRE CONNECT THE CDI ORANGE WIRE WITH SUPPLIED PLUG/CONNECTOR OR SOLDER.
- FIND A RED W/ GREEN TRACER @ POWER RELAY AND SPLICE RED CDI WIRE USING SUPPLIED CONNECTOR MAKE SURE TO USE PLIERS TO PUSH METAL TAB THEN FOLD COVER OVER CONNECTOR. WE RECOMMEND SOLDERING THE SPLICE AS THESE CONNECTORS DO NOT WORK WELL.
- PLUG THE CDI BLUE WIRE INTO THE EXISTING OEM SERVICE PLUG WITH BLUE/ WHITE TRACER.
- REMAINING GREEN WIRE HAS AN EYELET TO BE ATTACHED TO THE NEG BATTERY OR GROUND DEPENDING ON WHERE YOU MOUNT THE CDI.

